

Top Ten Installation / Pre-Installation errors

- ⌘ **Not all of them are loose. Check hinges for wear before install.**
- ⌘ **Always check out the rear. Pull strike plate and check for material behind jamb during survey for poorly routed alarm wires, glass wrap-around, concrete back fill.**
- ⌘ **Check for bugs. Infestations can cause problems, check for insects and vermin during survey.**
- ⌘ **They're all different. Always survey all hardware and jambs. A mix of hardware & jambs are not uncommon.**
- ⌘ **Protection. Pre tape jamb before layout & cutting jamb for strike.**
- ⌘ **Last Call. Old is not always good, old wiring can be causing a problem now or later.**
- ⌘ **Clean it up. Pre drill corners of strike prep during install then file corners for clean appearance.**
- ⌘ **AC/DC. Always check before, Integration of access components, make sure they match.**
- ⌘ **Size Matters. Always double check your wiring layout with a chart reference.**
- ⌘ **A good strip is worth the time. Do not take off too much, Insulation or wire strand.**