



Understanding the ROFU strike model numbers

AA - BB - CC - USXX

Series (AA)

14 Series - 44mm Keeper (Fail Secure)
 15 Series - 33mm Keeper (Fail Secure)
 17 Series - Adjustable Keeper (Fail Secure)
 18 Series - Adjustable Keeper (Fail Secure)
 19 Series - Rim Mount (Fail Secure)
 24 Series - (Fail Safe/Fail Secure)
 26 Series - (Fail Safe/Fail Secure)
 34 Series - 44mm Keeper (Fail Safe)
 39 Series - Rim Mount (Fail Safe)

Voltages (CC)

01	3-6VDC or 8-16VAC
04	12VAC (17 & 18 Series Only)
05	12VAC/12VDC
07	24VAC (17 & 18 Series Only)
08	24 VAC/24VDC
06	12VDC (Fail Safe Series)
09	24VDC (Fail Safe Series)
14	48VDC (17 Series Only)

Faceplate Size (BB)

00	Solenoid / Motor Part only
01	1 1/4" x 5 7/8"
02	1 1/4" x 4 7/8" Centerline
03	1 1/4" x 6 7/8" Centerline
04	1 7/16" x 7 15/16" Centerline
05	1 1/4" x 5 7/8" (15 Series)
07	1 1/8" x 2 3/4" T-Strike (15 Series)
09	1 7/16 x 7 15/16" Centerline (15 Series)
12	Rim Narrow (Front or Side) (15 Series)
30	1 1/4" x 4 7/8" Below Centerline / High Sec.
40	1 1/4" x 4 7/8" Below Centerline / High Sec.
50	1 1/4" x 4 7/8" Centerline / High Sec.
60	1 1/4" x 9" Centerline / High Sec.
70	1 1/4" x 9" Centerline / High Sec.
60	1 3/4" x 9 1/2" Rim Mount / High Sec.

Finish Designation (XX)

All finishes not available on all faceplates

US3 - Polished Brass
 US4 - Satin Brass
 US10B - Oil Rubbed Bronze (Duronatic)
 US26D - Satin Chrome
 US28 - Satin Aluminum
 US32D - Satin Stainless Steel
 US40 - Medium Bronze (Duronatic)

Misc. ROFU Strike Terms

LM - Latch Monitor
 LMCM - Latch Monitor, Cam Monitor
 RR/SKG - Latch Monitor, Cam Monitor
 FAFIX - Adjustable Keeper
 B - Bolt Cut-out
 RAD - Radius Faceplate
 R - Right Handed Solenoid
 L - Left Handed Solenoid

ROFU International Corp.
10029 South Tacoma Way, Suite E-11
Lakewood, WA 98499
Ph. 800-255-ROFU / Fax 888-840-7272