




- WIRING INSTRUCTIONS—
magnetic lock or fail safe strike with button,
keypad and PIR
wired in series



Depressing the push button, activating the keypad or activating the PIR would open the circuit, stopping the flow of electricity and causing the magnet or strike to release.

Power Supply for fail safe strikes and magnetic locks should be DC. If this is not available you may use an AC power source and wire inline a "Full Wave Bridge" rectifier. This will convert the AC to DC. If you hear a "buzzing" sound, recheck your output on your power source to ensure that it is DC output, or you can damage the magnetic lock or fail safe strike.